

## Repair of crack in the boat transom

1. Remove the alu-plates (and the drain tube if necessary).
2. Drill a hole through the plastic where the crack ends. Expand the crack somewhat with a knife.
3. Fill the crack with Terhi Fix and reinforce with a strip of fibreglass mat *or* glue a plate of ABS-plastic over the whole damaged area. Use screws (which can be removed when the Fix is dry) to mount the plate. Fill the holes and even the edges. Let dry.
4. Sand, paint and re-install the alu-plates (and the drain tube).

### Materials needed

ABS-plate or fibreglass mat

2 x Terhi Fix 300g

1 x Terhi Paint

Drain tube (when needed)



### NOTE

The surfaces have to be clean and dry before repairing. Temperature min +15C also during the drying.